

E5CN

OMRON

Temperature controller

Instruction Manual

Thank you for purchasing the OMRON E5CN temperature controller. Read this manual carefully before using the controller and always keep it close at hand while the controller is in use.

OMRON CORPORATION

©All Rights Reserved

For detailed operating instructions, please refer to the E5CN User's Manual.

Significance of WARNINGS and CAUTIONS



Indicates information that, if not heeded, could result in relatively serious or minor injury, damage to the product, or faulty operation.

N1

0682722-0G

PRECAUTIONS IN USING THE PRODUCT

When the product is used under the circumstances or environment below, ensure adherence to limitations of the ratings and functions. Also, take countermeasures for safety precautions such as fail-safe installations.

- Use under circumstances or environment which are not described in the instruction manual.
- Use for nuclear power control, railway, aircraft, vehicle, incinerator, medical equipment, entertainment equipment, safety device etc...
- Use for applications where death or serious property damage is possible and extensive safety precautions are required.

NOTICE

(1) Do not use this product in the following places:

- Places directly subject to heat radiated from heating equipment.
- Places subject to splashing liquid or oil atmosphere.
- Places subject to direct sunlight.
- Places subject to dust or corrosive gas (in particular, sulfide gas and ammonia gas).
- Places subject to intense temperature change.
- Places subject to icing and condensation.
- Places subject to vibration and large shocks.

(2) Use/store within the rated temperature and humidity ranges. Provide forced-cooling if required.

(3) To allow heat to escape, do not block the area around the product. Do not block the ventilation holes on the product.

(4) Be sure to wire properly with correct polarity of terminals.

(5) Use specified size (M3.5, width 7.2 mm or less) crimped terminals for wiring.

(6) Do not wire the terminals which are not used.

(7) Allow as much space as possible between the controller and devices that generate a powerful high-frequency or surge.

Separate the high-voltage or large-current power lines from other lines, and avoid parallel or common wiring with the power lines when you are wiring to the terminals.

(8) Use this product within the rated load and power supply.

(9) Make sure that the rated voltage is attained within two seconds of turning the power ON.

(10) Make sure the controller has 30 minutes or more for warm up.

(11) When executing self-tuning, turn the load and the unit ON simultaneously, or turn the load ON before you turn the controller ON.

(12) A switch or circuit breaker should be provided close to this unit. The switch or circuit breaker should be within easy reach of the operator, and must be marked as a disconnecting means for this unit.

(13) If you remove the controller from its case, or put the controller into its case, never touch nor apply shock to the terminals and the electronic parts inside. Make sure the electronic components and the case are not contacted when inserting the internal mechanism.

(14) Cleaning: Do not use paint thinner or the equivalent. Use standard grade alcohol to clean the product.


Specifications

Power supply voltage	100-240V/AC type 24V AC/DC type
Operating frequency	50-60Hz
Operating voltage range	85 to 110% of the rated voltage
Power consumption	Approx. 4VA (AC24V) Approx. 3W (DC24V)
Indication accuracy	Thermocouple, platinum resistance thermometer: (±0.5% of indication value or ±1°C, which is greater) ±1 digit max. Analog input: ±0.5% FS ±1 digit max.
Event input	input current: approx. 7 mA per contact.
Contact input	ON: 1 kΩ max., OFF: 100 MΩ min.
No-contact input	ON: residual voltage 1.5 V max., OFF: leakage current 0.1 mA max.
Control output 1	Relay output: SPST-NO, 250 VAC, 3A(resistive load) Voltage output: 12 VDC, 21 mA Current output: 4 to 20 mA DC, load 600 Ω max. Electrical life of relay: 100,000 operations ON/OFF or 2-PID control SPST-NO, 250 VAC, 1 A(resistive load), electrical life: 100,000 operations
Ambient temperature	-10 to 55°C
Ambient humidity	(Avoid freezing or condensation) RH 25 to 85%
Storage temperature	-25 to 65°C (Avoid freezing or condensation)
Altitude	Max. 2,000m
Recommended fuse	T2A, 250V AC, time-lag, low-breaking capacity
Weight	Approx. 150g (main unit only)
Installation environment	Setup category II, pollution degree 2 (as per IEC61010-1)

Wiring

Dimensions


Dimensions (mm)




* The main unit can be removed for maintenance without disconnecting the terminal wiring.

Installation

Individual mounting (mm)



Side-by-side mounting (waterproof not possible) (mm)



When waterproofing is required, be sure to mount the controller separately. Attach the waterproof packing from the terminal side and then insert the controller to the panel. Recommended panel thickness is 1 to 5 mm.

- Insert the controller through the hole in the panel. Push the adapter on from the rear and fasten temporarily, removing any gap between the controller, panel and adapter. Finally, secure two fixing screws alternately keeping the torque to between 0.29 to 0.39 N·m.
- Make sure that the surrounding temperature does not exceed the allowable operating temperature given in the specifications especially when two or more controllers are mounted.

Names of parts on front panel

• Level key Use this key to change levels: • Press the key and the key together for at least 3 seconds to switch to protect level.	• Mode key Press this key to change the contents of the display	• No.1 display Process value or set data symbol	• Operation indicators • ALM1: Alarm 1 output indicator Lights when alarm 1 output is ON. • ALM2: Alarm 2 output indicator Lights when alarm 2 output is ON. • HB: heater burnout alarm indicator Lights when heater burnout alarm is ON. • OUT1: control output 1 indicator Lights when control output 1 is ON and goes off when control output 1 is OFF. • OUT2: control output 2 indicator Lights when control output 2 is ON and goes off when control output 2 is OFF. • STOP: control stop indicator Lights when event input or "Run/Stop" is stopped during operation. During control stop, functions other than control output are valid. • CMW: communications writing enable/disable indicator Lights when communications writing is "enabled" and is out when it is "disabled".	• °C / °F : temperature unit The temperature unit is displayed when the displayed value is a temperature. When this parameter is set to "°C", "°C" is displayed, and when set to "°F", "°F" is displayed. This flashes while ST(Self-Tuning) is activated.
--	--	--	---	---

Operation menu

Input type

Input type	Input	Setting	Setting range
Platinum resistance thermometer	PT100	0	-200 to 850 (°C) / -300 to 1500 (°F)
	1	-199.9 to 500.0 (°C) / -199.9 to 900.0 (°F)	
	2	0.0 to 100.0 (°C) / 0.0 to 210.0 (°F)	
	3	-199.9 to 500.0 (°C) / -199.9 to 900.0 (°F)	
	4	0.0 to 100.0 (°C) / 0.0 to 210.0 (°F)	

Input type	Input	Setting	Setting range
Thermocouple	K	0	-200 to 1300 (°C) / -300 to 2300 (°F)
	1	-20.0 to 500.0 (°C) / 0.0 to 900.0 (°F)	
	2	-100 to 850 (°C) / -100 to 1500 (°F)	
	3	-20.0 to 400.0 (°C) / 0.0 to 750.0 (°F)	
	4	-200 to 400 (°C) / -300 to 700 (°F)	
	17	-199.9 to 400.0 (°C) / -199.9 to 700.0 (°F)	
	5	0 to 600 (°C) / 0 to 1100 (°F)	
	6	-100 to 850 (°C) / -100 to 1500 (°F)	
	7	-200 to 400 (°C) / -300 to 700 (°F)	
	18	-199.9 to 400.0 (°C) / -199.9 to 700.0 (°F)	
	8	-200 to 1300 (°C) / -300 to 2300 (°F)	
	9	0 to 1700 (°C) / 0 to 3000 (°F)	
	S	0 to 1700 (°C) / 0 to 3000 (°F)	
	B	100 to 1800 (°C) / 300 to 3200 (°F)	
Infrared Thermosensor	ES1A	10 -70°C	0 to 90 (°C) / 0 to 190 (°F)
		60 -120°C	0 to 120 (°C) / 0 to 240 (°F)
		115 -165°C	0 to 165 (°C) / 0 to 320 (°F)
		160 -260°C	0 to 260 (°C) / 0 to 500 (°F)

* Default = "0"
• Alarms

Setting	Alarm type	Alarm output function
0	No alarm function	Positive alarm value (X) / Negative alarm value (X)
1	Deviation upper/lower limit	ON OFF SP
2	Deviation upper limit	ON OFF SP
3	Deviation lower limit	ON OFF SP
4	Deviation upper/lower range	Vary with "L", "H" values
5	Deviation upper/lower limit standby sequence ON	Vary with "L", "H" values
6	Deviation upper limit standby sequence ON	ON OFF SP
7	Deviation lower limit standby sequence ON	ON OFF SP
8	Absolute value upper limit	ON OFF SP
9	Absolute value lower limit	ON OFF SP
10	Absolute value upper limit standby sequence ON	ON OFF SP
11	Absolute value lower limit standby sequence ON	ON OFF SP

*1: Upper and lower limits can be set for parameters 1, 4 and 5 to provide for different types of alarm. These are indicated by the letter "L" and "H".

* Default = "2"

Error display (trouble shooting)

When an error has occurred, the No.1 display alternately indicates error codes together with the current display.

No.1 display	Meaning	Action	Status at error
SErr (S. Err)	Input error *2	Check the wiring of inputs, disconnections, shorts and input type.	OFF
	A/D converter error *2	After the correction of input error, turn the power OFF and then ON again. If the error still occurs, the power must be repaired. If the display is restored to normal, then a probable cause can be external noise affecting the control system. Check for external noise.	OFF
E!!! (E111)	Memory error	Turn the power OFF and then back ON again. If the display is restored to normal, then a probable cause can be external noise affecting the control system. Check for external noise.	OFF
HErr (H. Err)	Internal circuit error *2		OFF OFF

If the input value exceeds the display limit (-1999(-199.9) to 9999(999.9)), though it is within the control range, [cccc] will be displayed under -1999(-199.9) and [9999] above 9999(999.9). Under these conditions, control output and alarm output will operate normally.

Refer to "E5CN User's Manual" for details of control range.

*2: Error shown only for "Process value / Set point". Not shown for other status.

Other functions

In addition to the aforementioned, there are alarm hysteresis, automatic return of display mode and others in the advanced setting level.

Refer to "E5CN User's Manual" for details.

For communications details, please refer to "E5AN/EN/CN/GN communications User's Manual".

OMRON ELECTRONICS, INC.
1 East Commerce Drive, Schaumburg, Illinois 60173 U.S.A.
Phone 1-847-843-7900 FAX:1-847-856-7787

EUROPEAN HQ : OMRON EUROPE B.V.
Wegalaan 67-69 2132 JD

形E5CN

OMRON

電子温度調節器

J 取扱説明書

オムロン製品をお買い上げいただきありがとうございます。この製品を安全に正しく使用していただくために、お使いになる前にこの取扱説明書をお読みになり、十分にご理解ください。お読みになった後も、いつも手元に置いてお使用してください。

オムロン株式会社

©All Rights Reserved


詳細な使用方法は別冊「形E5CN/CN-Uユーチューズマニュアル」を参照してください。

注意・警告の意味


△ 注意 誤った取り扱いをすると、人が傷害を負ったり、物的損害の発生が想定される場合を示します。

配線

●外形寸法図



●取り付け



●接続 (機種によって端子の用途は異なります。)

