

●SAFETY PRECAUTIONS●

(Always read these precautions before using this equipment.) Before using this product, please read this manual and the relevant manuals introduced in this manual carefully and pay full attention to safety to handle the product correctly. The precautions given in this manual are concerned with this prod-

uct In this manual, the safety precautions are ranked as "DANGER" and "CAUTION"

| DANGER | Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury. |
|--------|---|
| | Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage. |

Note that the \triangle CAUTION level may lead to a serious accident

according to the circumstances. Always follow the precautions of both levels because they are impor-tant to personal safety.

Please save this manual to make it accessible when required and always forward it to the end user

3. Installation Procedure

Remove the old protective sheet from the GOT, and clean the GOT surface. (Peel the protective sheet off slowly.)



(2) Peel the release paper from the back of the new protective sheet, and attach its adhesive side to the GOT display section

When attaching the protective sheet, make sure to fit it on the display section closely without leaving any clearance between them



[INSTALLATION PRECAUTIONS]

A CAUTION

When attaching the protective sheet onto the GOT display section, make sure to fit the protective sheet onto the section closely without leaving any clearance between them. Failure to do so may cause a malfunction

[STARTUP AND MAINTENANCE PRECAUTIONS]

| • | Daily check the protective sheet with eyes. When you find extreme dirt or scratches on the surface, immediately replace it |
|---|--|
| | with new one. |
| | Using the productive sheet of decreased visibility may cause a |
| | malfunction. |

[DISPOSAL PRECAUTIONS]

A CAUTION

Dispose of this product as industrial waste.

| <u>Manuals</u> | |
|-------------------------------------|------------------------------|
| The following shows manuals relevan | t to this product. |
| Detailed Manual | |
| Manual name | Manual number (Type code) |
| GT15 User's Manual (Option) | SH-080528ENG (1D7M23) |

For relevant manuals, refer to the PDF manual stored within the drawing software used.

© 2004 MITSUBISHI ELECTRIC CORPORATION

1. Overview

This User's Manual describes the GT15 protective sheet (hereafter abbreviated to the protective sheet) There are the following protective sheet types. Refer to the GT15 User's Manual for the applicable GOT.

| Product name | Model name | Description |
|--------------|----------------|--|
| | GT15-90PSCB | 15" protective sheet Clear |
| | GT15-90PSGB | 15" protective sheet Antiglare |
| | GT15-90PSCW *1 | 15" protective sheet Clear (Frame: White) |
| | GT15-90PSGW *1 | 15" protective sheet Antiglare (Frame: White) |
| | GT15-80PSCB | 12.1" protective sheet Clear |
| | GT15-80PSGB | 12.1" protective sheet Antiglare |
| | GT15-80PSCW *1 | 12.1" protective sheet Clear (Frame: White) |
| | GT15-80PSGW *1 | 12.1" protective sheet Antiglare (Frame: White) |
| | GT15-70PSCB | 10.4" protective sheet Clear |
| Protective | GT15-70PSGB | 10.4" protective sheet Antiglare |
| sheet | GT15-70PSCW *1 | 10.4" protective sheet Clear (Frame: White) |
| | GT15-70PSGW *1 | 10.4" protective sheet Antiglare (Frame: White) |
| | GT15-60PSCB | 8.4" protective sheet Clear |
| | GT15-60PSGB | 8.4" protective sheet Antiglare |
| | GT15-60PSCW *1 | 8.4" protective sheet Clear (Frame: White) |
| | GT15-60PSGW *1 | 8.4" protective sheet Antiglare (Frame: White) |
| | GT15-50PSCB | 5.7" protective sheet Clear |
| | GT15-50PSGB | 5.7" protective sheet Antiglare |
| | GT15-50PSCW *1 | 5.7" protective sheet Clear (Frame: White) |
| | GT15-50PSGW *1 | 5.7" protective sheet Antiglare (Frame: White) |

*1 The frame is white. Use it when making the GOT front section (other than the display section) white.

Use the protective sheet to protect the display section surface from scratches and dirt when operating the touch keys on the GOT display section. Select the clear protective sheet when the display intensity is more required, or select the antiglare protective sheet when

prevention of reflections is more required.

2. Part Names and External Dimensions

(1) 15"/12.1"/10.4"/8.4" protective sheet



| 15" Protective sheet | 381 (15.0) | 280 (11.0) |
|------------------------|------------|---------------|
| 12.1" Protective sheet | 310 (12.2) | 236 (9.3) |
| 10.4" Protective sheet | 297 (11.7) | 208 (8.2) |
| 8.4" Protective sheet | 235 (9.3) | 184 (7.2) |
| | Ur | it: mm (inch) |

(2) 5.7" protective sheet



| Item | A | В |
|-----------------------|----------|-----------------|
| 5.7" protective sheet | 160(6.3) | 131(5.12) |
| | | Unit .mm (inch) |

Warranty Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; machine damage or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

≜ For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi. This product has been manufactured under strict quality control.
- However, when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.

 Sales office/Tel
Mitsubishi Electric Automation Inc. 500 Corporate Woods Parkway Vernon Hills, IL 60061 Tel : +1-847-478-2100
MELCO-TEC Rep. Com. e Assessoria Tecnica Ltda. Rua Correia Dias, 184, Edificio Paraiso Trade Center-8 andar Paraiso, Sao Paulo, SP Brazil
Tel : +55-11-5908-8331
Mitsubishi Electric Europe B.V. German Branch Gothaer Strasse 8 D-40880 Ratingen, GERMANY Tel : +49-2102-486-0
Missubishi Electric Europe B.V. UK Branch Travellers Lane, Hatfield, Herts, AL 10 8X8,UK Tel : +44-1707-276100
Mitsubishi Electric Europe B.V. Italian Branch Centro Dir. Colleoni, Pal. Perseo-Ingr.2
Via Paracelso 12, 20041 Agrate B., Milano, Italy Tel : +39-039-6053344
Mitsubishi Electric Europe B.V. Spanish Branch Carretera de Rub 76-80
Og190 - Sant Cugat del Valles, Barcelona, Spain Country/Region Sales office/Tel U.S.A Brazil Germany U.K Italy Spair 08190 - Sant Cugat del Valles, Barcelona, Spain Tel : +34-93-565-3131 Ter: + 54-93-565-3131 Mitsubishi Electric Europe B.V. French Branch 25 Boulevard des Bouvets, F-92741 Nanterre Cedex, France TEL: + 33-1-5568-5568 Circuit Breaker Industries LTD. Tripswitch Drive, ElandStein Gauteng, South Africa Tel: + 27-11-928-2000 Ryndan Automatic France South Africa Hong Kong R ion Ltd. 10th Floor, Manulife Tower, 169 Electric

(3) Peel the protective film off the protective sheet.



| | Road, North Point, HongKong |
|-----------|--|
| | Tel : +852-2887-8870 |
| China | Ryoden Automation Shanghai Ltd. |
| | 3F Block5 Building Automation |
| | Instrumentation Plaza 103 Cao Bao Rd. Shanghai 200233 China |
| T | Tel : +86-21-6120-0808 |
| Taiwan | Setsuyo Enterprise Co., Ltd. |
| | 6F., No.105 Wu-Kung 3rd.RD, Wu-Ku Hsiang, |
| | Taipei Hsine, Taiwan |
| | Tel : +886-2-2299-2499 |
| Korea | HAN NEUNG TECHNO CO., LTD. |
| | 1F Dong Seo Game Channel Bldg.,660-11, Deungchon-dong |
| | Kangsec-ku, Seoul, Korea |
| 0 | Tel : +82-2-3660-9552 |
| Singapore | Mitsubishi Electric Asia Pte, Ltd. |
| | 307 Alexandra Road #05-01/02, |
| | Mitsubishi Electric Building Singapore 159943 Tel : +65-6473-2308 |
| Thailand | F. A. Tech Co.,Ltd. |
| Indianu | 898/28,29,30 S.V.City Building,Office Tower 2, Floor 17-18 Rama 3 |
| | Road, Bangkpongpang, Yannawa, Bangkok 10120 |
| | Tel : +66-2-682-6522 |
| Indonesia | P.T. Autoteknindo SUMBER MAKMUR |
| Indonesia | Jl. Muara Karang Selatan Block a Utara No.1 Kav. No.11 Kawasan |
| | Industri/Pergudangan Jakarta - Utara 14440 |
| | Tel : +62-21-663-0833 |
| India | Messung Systems Put,Ltd. |
| mana | Electronic Sadan NO:111 Unit No15, M.I.D.C BHOSARI. |
| | PUNE-411026. India |
| | Tel : +91-20-712-2807 |
| Australia | Mitsubishi Electric Australia Pty. Ltd. |
| | 348 Victoria Road, PostalBag, No 2, |
| | Rydalmere, N.S.W 2116, Australia |
| | Tel : +61-2-9684-7777 |
| • | |
| | |

MITSUBISHI ELECTRIC CORPORATION

HEAD OF HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN NAGOYA WORKS : 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice Printed in Japan on recycled paper.